

Getting Started

Video-to-FireWire Converter DFG/1394-1e

Quick start

- First of all, connect the converter and the computer
- Only then install the **WDM Stream Class driver**
- Install **IC Capture TIS**
- Install **IC Imaging Control TIS**

Starting with a checklist

The material you need

- PC or Laptop with PIII/800 MHz/256 MB or higher
- IEEE 1394 interface which complies with OHCI (such as the PCI/1394o1 or the CBI/1394-1)
- Cable to connect this 1394 interface to the converter (such as the CA/1394-64/x or the CA/1394-66/x)
- In case of a laptop the converter may require a power supply unit

Please make sure that you have

- setup Windows 2000/SP4 or Windows XP/SP2
- a graphics card with 24 or 32 bit
- setup DirectX 9.0c or higher
- setup an IEEE 1394 interface, which complies with OHCI (as the PCI/1394o1 or the CBI/1394-1)
- connected the converter to this interface

Software

Please follow these steps to install The Imaging Source driver:

- Please insert the included CD and click
 - (1) **Driver** in this first dialog
 - (2) **Install** in the following table (row "WDM Stream Class driver", first column)
- Start again with the CDs first dialog and click
 - (1) **Software for end users** in this first dialog
 - (2) **IC Capture** in the second dialog
 - (3) **Install IC Capture TIS** in the third dialog

For programmers only:

- Start again with the CDs first dialog and click
 - (1) **Software for programmers** in this first dialog
 - (2) **IC Imaging Control** (.NET component, ActiveX, C++ Class Library) in the second dialog
 - (3) **Install IC Imaging Control TIS** in the third dialog



EUROPEAN HEADQUARTERS
The Imaging Source Europe GmbH
Sommerstrasse 36, D-28215 Bremen, Germany
support@eu.theimagingsource.com
Phone: +49 421 33591-0

US HEADQUARTERS
The Imaging Source
1201 Greenwood Cliff, Charlotte, NC 28204
support@us.theimagingsource.com
Phone: +1 704-370-0110 USA
Toll Free: +1 877-462-4772 USA

All product and company names in this document may be trademarks and tradenames of their respective owners and are hereby acknowledged.

The Imaging Source Europe GmbH cannot and does not take any responsibility or liability for any information contained in this document. The source code presented in this document is exclusively used for didactic purposes. The Imaging Source does not assume any kind of warranty expressed or implied, resulting from the use of the content of this document or the source code.

The Imaging Source Company reserves the right to make changes in specifications, function or design at any time and without prior notice.

Last update: December 2005
Copyright © 2005 The Imaging Source Europe GmbH
All rights reserved. Reprint, also in parts, only allowed with permission of The Imaging Source Europe GmbH.

All weights and dimensions are approximate.