

Getting Started

Video-to-USB Converter DFG/USB2-It

Quick start

- First of all, connect the converter and the computer
- Only then install the **WDM Stream Class driver**
- Install **IC Capture TIS**
- Install **IC Imaging Control TIS**

Starting with a checklist

The material you need

- PC or Laptop with PIII/800 MHz/256 MB or higher
- USB2.0 interface
- Cable to connect this USB2.0 interface to the converter

Please make sure that you have

- setup Windows 2000/SP4 or Windows XP/SP2
- a graphics card with 24 or 32 bit
- setup DirectX 9.0c or higher
- setup a USB interface
- connected the converter to this interface

Software

Please follow these steps to install The Imaging Source driver:

- Please insert the included CD and click
 - (1) **Driver** in this first dialog
 - (2) **Install** in the following table (row "WDM Stream Class driver", first column)
- Start again with the CDs first dialog and click
 - (1) **Software for end users** in this first dialog
 - (2) **IC Capture** in the second dialog
 - (3) **Install IC Capture TIS** in the third dialog

For programmers only:

- Start again with the CDs first dialog and click
 - (1) **Software for programmers** in this first dialog
 - (2) **IC Imaging Control** (.NET component, ActiveX, C++ Class Library) in the second dialog
 - (3) **Install IC Imaging Control TIS** in the third dialog



EUROPEAN HEADQUARTERS
The Imaging Source Europe GmbH
Sommerstrasse 36,
D-28215 Bremen,
Germany

US HEADQUARTERS
The Imaging Source, LLC
7257 Pineville-Matthews Road,
Charlotte, NC 28226

www.theimagingsource.com/en

Alle Rechte vorbehalten. Die Installation dieses Produktes ist nur für den persönlichen Gebrauch bestimmt und darf nicht für kommerzielle Zwecke verwendet werden. Die Installation dieses Produktes ist nur für den persönlichen Gebrauch bestimmt und darf nicht für kommerzielle Zwecke verwendet werden.

The Imaging Source Europe GmbH übernimmt keine Verantwortung für Schäden, die durch die Verwendung dieses Produktes entstehen. Die Installation dieses Produktes ist nur für den persönlichen Gebrauch bestimmt und darf nicht für kommerzielle Zwecke verwendet werden. Die Installation dieses Produktes ist nur für den persönlichen Gebrauch bestimmt und darf nicht für kommerzielle Zwecke verwendet werden.

Copyright © 2005 The Imaging Source Europe GmbH
Alle Rechte vorbehalten. Die Installation dieses Produktes ist nur für den persönlichen Gebrauch bestimmt und darf nicht für kommerzielle Zwecke verwendet werden.

Alle Rechte vorbehalten. Die Installation dieses Produktes ist nur für den persönlichen Gebrauch bestimmt und darf nicht für kommerzielle Zwecke verwendet werden.